


Owners Manual



CS13H Series Water Softener

1. Read all instructions carefully before operation.
2. Avoid pinched o-rings during installation by applying (provided with install kit) NSF certified lubricant to all seals.
3. This system is not intended for treating water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.




TABLE OF CONTENTS

| | |
|--|------------------|
| <i>READ THIS PAGE FIRST</i> | <i>4</i> |
| <i>WATER CONDITIONER BASICS</i> | <i>5</i> |
| <i>SOFTENER SYSTEM SPECIFICATIONS</i> | <i>6</i> |
| <i>SOFTENER SYSTEM DIMENSIONS</i> | <i>7</i> |
| <i>UNPACK & INSPECT YOUR WATER SOFTENER</i> | <i>8</i> |
| <i>CHECK THE VALVE SERIAL NUMBER</i> | <i>9</i> |
| <i>CHECK THE SOFTENER SERIAL NUMBER</i> | <i>10</i> |
| <i>PARTS BREAKDOWN</i> | <i>11</i> |
| <i>PRE-INSTALLATION INSTRUCTIONS</i> | <i>15</i> |
| <i>INSTALLATION INSTRUCTIONS</i> | <i>15</i> |
| <i>WATER BYPASS</i> | <i>17</i> |
| <i>PROGRAMMING GUIDE</i> | <i>18</i> |
| <i>START-UP INSTRUCTIONS</i> | <i>22</i> |
| <i>MAINTENANCE INSTRUCTIONS</i> | <i>24</i> |
| <i>TROUBLE SHOOTING GUIDE</i> | <i>30</i> |

READ THIS PAGE FIRST

BEFORE STARTING INSTALLATION

- ▶ You must read and understand the contents of this manual before installing or operating your water softener.
Personal injury or property damage could result if you fail to follow instructions in this manual.
 - ▶ This system and its installation must comply with state and local regulations. Check with your local public works department for plumbing and sanitation codes. Local codes should be followed in the event the codes conflict with any content in this manual.
 - ▶ This water Softener must be operated on pressures between 30 psi to 125 psi. If the water pressure is higher than 125 PSI, use a pressure reducing valve in the water supply line to the softener.
 - ▶ This unit must be operated at temperatures between 4°C - 43°C (40°F and 110°F)
 - ▶ Do not use this water softener on hot water supplies.
 - ▶ Do not install this unit where it may be exposed to wet weather, direct sunlight, or temperatures outside of the range specified above.
 - ▶ The appliance is only to be used with the power supply unit provided with the appliance.
 - ▶ The appliance must only be supplied at safety extra low voltage corresponding to the marking on the appliance.
 - ▶ Apply provided NSF certified lubricant to all o-rings during installation. Do not use pinched or damaged o-rings during installation.
 - ▶ Softeners are exposed to high levels of iron, manganese, sulfur, and sediments. Damage to pistons, seals, and/or spacers within the control valve are not covered in this warranty due to the harsh environment.
 - ▶ It is recommended to annually inspect and service the control valve. Frequent cleaning and/or replacement of piston, seals, and/or spacers may be necessary depending on how harsh the conditions are.
 - ▶ Do not use water that is microbiologically unsafe without adequate disinfection before or after this system.
 - ▶ This publication is based on information available when approved for printing. Continuing design refinement could cause changes that may not be included in this publication.
 - ▶ This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
 - ▶ Children shall not play with the appliance.
 - ▶ Cleaning and user maintenance shall not be made by children without supervision.
- Canature Environmental Products Co., Ltd guarantees that your new water conditioner is built of quality material and workmanship. When properly installed and maintained, it will give years of trouble free service.

Canture reserves the right to change the specifications referred to in this literature at any time, without prior notice.

INSTALL NOTES & SAFETY MESSAGES

Watch for the following messages in this manual:

EXAMPLE:

NOTE

Check and comply with your state and local codes. You must follow these guidelines.

EXAMPLE:



CAUTION

Disassembly while under pressure can result in flooding.

EXAMPLE:



WARNING

Electrical Shock Hazard! Unplug the unit before removing the cover or accessing any internal control parts.

WATER CONDITIONER BASICS

WHAT IS HARD WATER AND HOW IT IS SOFTENED

All of the fresh water in the world originally falls as rain, snow, or sleet. Surface water evaporates and is drawn upward by the sun, forming clouds. Then, nearly pure and soft as it starts to fall as rain. It begins to collect impurities as it passes through smog and dustladen atmosphere back to the ground. And as it seeps through soil and rocks it gather hardness, rust, acid, unpleasant tastes and odors.

Water hardness is caused primarily by limestone dissolved from the earth by the rainwater. Because of this, in earlier times, people who wanted soft water collected rainwater from roofs in rain barrels and cisterns before it picked up hardness from the earth.

Some localities have corrosive water. A softener cannot correct this problem. This softner has warranty disclaims of liability for corrosion of plumbing lines, fixtures or appliances.

Iron is a common water problem. The chemical/physical nature of iron found in natural water supplies is exhibited in four general types:

1. DISSOLVED IRON—Also calqlod ferrous or “clear water” iron. Dissolved iron is soluble in water and is detected by taking a sample of the water to be treated in a clear glass. The water in the glass is initially clear, but on standing exposed to the air, it may gradually turn cloudy or colored as it oxidizes. This type of iron can be removed from the water by the same ion exchange principle that removes the hardness elements, calcium and magnesium.

2. PARTICULATE IRON—Also called ferric or colloidal iron. This type of iron is an undissolved particle of iron. A filtering treatment will be required to remove this type of iron. A softener will remove larger particles, but the particles may not be washed out in regeneration effectively and will eventually foul the ion exchange resin.

3. ORGANIC BOUND IRON—This type of iron is strongly attached to an organic compound in the water. The ion exchange process alone cannot break this bond down and the softener will not remove this type of iron.

4. BACTERIAL IRON—This type of iron is protected inside a bacteria cell. Like the organic bound iron, it is not removed by a water softener.

It's important that when a softener is removing both hardness and dissolved iron, it must regenerate more frequently than it normally would for just hardness. Many factors and formulas have been used to determine this frequency. It is recommended that the softener be regenerated when it has reached 50–75% of the calculated hardness alone capacity. This will minimize the potential for bed fouling.

Regular resin bed cleaning is needed to keep the bed from coating with iron if you are operating a water softener on clear water iron. Even when operating a softener on water with less than the maximum of dissolved iron, regular cleanings should be performed. Clean every six months or more often if iron appears in your conditioned water supply. Use resin bed cleaning compounds carefully following the directions on the container.



CAUTION

DO NOT USE WATER FILTERED THROUGH THIS SOFTENER WHERE THE WATER IS MICROBIOLOGICALLY UNSAFE OR THE WATER IS OF UNKNOWN QUALITY. THE WATER MUST BE DISINFECTED BEFORE OR AFTER THE UNIT.




SOFTENER SYSTEM SPECIFICATIONS

CANATURE BNT850 DF VALVE



| Performance Data Sheet and Specifications | | |
|---|--|------------|
| Model | CS13H-1017 | CS13H-1035 |
| Control System | BNT-850 Control Valve | |
| Regeneration Type | Down Flow | |
| Integrated Meter in Bypass | Yes | Yes |
| Hardness Removal(6 lb/cf Salt Dosage) | 704 Gram | 1408 Gram |
| Media Loaded | Yes | Yes |
| Resin Quantity | 12.5 L | 25 L |
| Resin Type | Extremely High Capacity Ion Exchange Resin - Exclusive | |
| Tank Size | 10x17 | 10x35 |
| Salt Storage Capacity | 18 Kg | 48 Kg |
| Recommended Service Flow Rate | 6.7 L/M | 13 L/M |
| Recommended Cycle Settings | | |
| Backwash Duration Setting | 3 Min | 5 Min |
| Brine Duration Setting | 20 Min | 52 Min |
| Rinse Duration Setting | 1 Min | 3 Min |
| Refill Duration Setting | 4.4 Min | 8.8 Min |
| Salt Used - Per Regeneration(6 lb/cf Salt Dosage) | 1.2 Kg | 2.4 Kg |
| Water Used - Regeneration | 60 L | 130 L |
| Flow Rate(Only valve) | | |
| Continuous Flow Rate @ 15 psi Pressure Drop | 4500L/H | |
| Peak Flow Rate @ 25 psi Pressure Drop | 5900L/H | |
| Back Wash Flow Rate@ 25 psi Pressure Drop | 1600L/H | |
| Shipping Weight | 21 Kg | 50 Kg |
| Pipe Size | 3/4" or 1" | |
| Plumbing Connections | Includes 3/4" Straight Fittings | |
| Electrical Requirements | Input 110V-120V / 220-240V AC 50/60Hz | |
| | Output 12V AC 650mA | |
| Water Temperature | 3 ~ 38 °C | |
| Water Pressure | 0.14 ~ 0.86MPa | |

- Capacities of conditioners may deviate from the chart above depending on flow rates and raw water conditions.
- Changing salt settings from factory setting may require changing injector sizes to achieve stated capacities.
- Hardness removal is based on standard salt setting(6lbs/cf).
- Iron content must not exceed 1 ppm. Beyond 1 ppm an iron softener must be used.
- Do not subject the unit to freezing temperatures.
- Do not use water that is microbiologically unsafe without adequate disinfection before or after the system.
- The manufacturer reserves the right to make product improvements which may deviate from the specifications and descriptions stated herein, without obligation to change previously manufactured products or to note the change.


SOFTENER SYSTEM DIMENSIONS



1017 TANK



1035 TANK



UNPACK & INSPECT YOUR WATER SOFTENER

Inspect the water softener for any shipping damage. If damage is found, notify the transportation company and request a damage inspection. Damage to cartons should also be noted.


Handle the softener unit with care. Do not drop the unit or set on sharp, uneven projections on the floor. Do not turn the softener unit upside down.

NOTE

IF THERE IS A SEVERE LOSS IN WATER PRESSURE WHEN THE SOFTENER UNIT IS INITIALLY PLACED IN SERVICE, THE SOFTENER TANK MAY HAVE BEEN LAID ON ITS SIDE DURING TRANSIT. IF THIS OCCURS, BACKWASH THE SOFTENER TO "RECLASSIFY" THE MEDIA.


The manufacturer is not responsible for damages in transit. Small parts, needed to install the Softener, are in a parts box. To avoid loss of the small parts, keep them in the parts bag until you are ready to install.

ACCESSORIES CONTENTS :



CHECK THE VALVE SERIAL NUMBER

Check to make sure the valve type matches what you ordered. The valve configuration sticker will show the injector, BLFC and DLFC size. The valve model sticker shows model, hardware/software version, serial # and batch code of the control valve. Serial numbers are important for troubleshooting.




VALVE SERIAL NUMBER:

22018178N730001

Valve Part # Year Month Date Batch code

(22018178): Valve part #
(N)YEAR: "N" stand for year 2017, "M" stand for year 2016, "L" stand for year 2015, "K" stand for year 2014...
(7)MONTH: 1(JAN), 2(FEB), 3(MAR), 4(APRIL), 5(MAY), 6(JUNE), 7(JULY), 8(AUG), 9(SEP), A(OCT), B(NOV), C(DEC)
(3)DATE: 1 2 3 4 5 6 7 8 9 (A)10 (B)11 (C)12 (D)13 (E)14 (F)15 (G)16 (H)17 (I)18 (J)19 (K)20 (L)21 (M)22 (N)23 (O)24 (P)25 (Q)26 (R)27 (S)28 (T)29 (U)30 (V)31
(0001): Batch code

CHECK THE SOFTENER SERIAL NUMBER



00284039N890001

Valve Part # Year Month Date Batch code

(00284039): Softener part #

(N)YEAR: "N" stand for year 2017, "M" stand for year 2016, "L" stand for year 2015, "K" stand for year 2014...


(8)MONTH: 1(JAN), 2(FEB), 3(MAR), 4(APRIL), 5(MAY), 6(JUNE), 7(JULY), 8(AUG), 9(SEP), A(OCT), B(NOV), C(DEC)

(9)DATE: 1 2 3 4 5 6 7 8 9 (A)10 (B)11 (C)12 (D)13 (E)14 (F)15 (G)16 (H)17 (I)18 (J)19 (K)20 (L)21 (M)22 (N)23 (O)24 (P)25 (Q)26 (R)27 (S)28 (T)29 (U)30 (V)31

(0001): Batch code

PARTS BREAKDOWN


SOFTENER PARTS LIST



| No. | Part # | Description | Qty |
|-----|-----------|----------------------------------|-----|
| A1 | 21710104B | Brine Well Clamp | 1 |
| A2 | 07010013G | 0417 Brine Valve Assy | 1 |
| | 07010014G | 0435 Brine Valve Assy | 1 |
| A3 | 07030054W | 0417 Brine Well | 1 |
| | 07030055W | 0435 Brine Well | 1 |
| A4 | 07030098 | Brine Well Cap | 1 |
| A5 | 07000207D | CS13-1017 Softener Cabinet(Grey) | 1 |
| | 07000208D | CS13-1035 Softener Cabinet(Grey) | 1 |
| A6 | 07030463D | Rotary Cover(Orange) | 1 |
| A7 | 07030462E | Adding Salt Cover(Orange) | 1 |
| A8 | 50030150C | Controller label | 1 |
| A9 | 05030020 | Controller Display PCB | 1 |
| A10 | 13000401 | Screw 2.9×6.5 | 4 |
| A11 | 07030461E | Softener Cover(Orange) | 1 |

| | | | |
|-----|-----------|------------------------------|---|
| A12 | 07030464C | Controller Front Cover(Grey) | 1 |
| A13 | 05010037 | Screw 2.9×10 | 3 |
| A14 | 05030044 | Controller Back Cover(Black) | 1 |
| A15 | 13000426 | Screw 2.9×6.5 | 4 |
| A16 | 02170173 | Overflow assy | 1 |
| A17 | 21710110 | Pressure Tank Clamp | 1 |
| A18 | 07501017 | 1017 Pressure Tank | 1 |
| | 07501035 | 1035 Pressure Tank | 1 |
| A19 | 02030018 | Distribution Tube Assy-1017 | 1 |
| | 02030016 | Distribution Tube Assy-1035 | 1 |
| A20 | 07060009 | Top Cone | 1 |
| A21 | 22018178 | Control Valve Assy | 1 |
| A22 | 22053014G | Bypass Valve Assy | 1 |


VALVE BODY PARTS LIST



| No. | Part # | Description | Qty |
|-----|-----------|--------------------------------|-----|
| B1 | 05056508 | Screw-M5×12(with Washer) | 5 |
| B2 | 05030004 | Bnt85 End Cover | 1 |
| B3 | 05030013 | O-ring-φ30×2.65 | 1 |
| B4 | 05056084 | Screw-ST3.5×13 | 2 |
| B5 | 07060007 | Valve Bottom Connector | 1 |
| B6 | 26010103 | D-tube O-ring | 1 |
| B7 | 05056063 | Tank O-ring | 1 |
| B8 | 05030001 | Bnt85 Valve Body | 1 |
| B9 | 05056073 | Seal | 5 |
| B10 | 05056204 | Spacer | 8 |
| B11 | 05056520 | Piston | 1 |
| B12 | 05056022B | Piston Retainer | 1 |
| B13 | 05056097 | Piston Pin | 1 |
| B14 | 05005605 | End Plug | 1 |
| B15 | 05030002B | Bnt85 Piston Rod | 1 |
| B16 | 02170054 | Piston Assy | 1 |
| B17 | 05056047 | End Plug Retainer | 1 |
| B18 | 05056087 | Screw-M5×12 | 3 |
| B19 | 05056088 | Screw-M5×16 | 2 |
| B20 | 05056180M | Brine Valve Injector Stem Assy | 1 |

| | | | |
|-----|-----------|----------------------|---|
| B21 | 05056066 | O-Ring-φ11×2 | 1 |
| B22 | 05056037 | Air Disperser | 1 |
| B23 | 05056067 | O-Ring-φ7.8×1.9 | 2 |
| B24 | 05056177 | Injector Body | 1 |
| B25 | 05056103 | Injector Screen | 1 |
| B26 | 30040083 | Injector Throat(Red) | 1 |
| B27 | 30040084 | Injector Nozzle(Red) | 1 |
| B28 | 05056205 | O-RING(23.9×1.8) | 1 |
| B29 | 05056029 | Injector Cover | 1 |
| B30 | 05056086 | Screw-M5×30 | 2 |
| B31 | 05056172 | Secure Clip-S | 1 |
| B32 | 05056188 | DLFC(2.0GPM) | 1 |
| B33 | 05056134 | O-ring 12×2 | 1 |
| B34 | 05010082 | Drain Elbow | 1 |
| B35 | 05056035 | BLFC Button Retainer | 1 |
| B36 | 05056076 | BLFC(0.3GPM) | 1 |
| B37 | 05056138 | O-Ring-φ14×1.8 | 1 |
| B38 | 05056100B | BLFC Copper Fitting | 1 |
| B39 | 05056033 | BLFC Ferrule | 1 |
| B40 | 05056108 | BLFC Fitting Nut | 1 |
| B41 | 21499033 | Brine Line QC Elbow | 1 |


POWER HEAD PARTS LIST



| No. | Part # | Description | Qty |
|-----|----------|-----------------------------|-----|
| C1 | 05030020 | Display Board | 1 |
| C2 | 05056084 | Screw-ST3.5×13 | 1 |
| C3 | 05030024 | Bnt 85 Cover | 1 |
| C4 | 05056550 | Bnt85 Motor | 1 |
| C5 | 05030006 | Bnt85 Mounting Plate | 1 |
| C6 | 05010037 | Screw-ST2.9×10 | 1 |
| C7 | 05030010 | Bnt85 Main Pcb | 1 |
| C8 | 13000462 | Screw-4.2×12(with washer) | 1 |
| C9 | 05010023 | Magnet-φ3×2.7 | 1 |
| C10 | 05030008 | Bnt85 Brine Gear | 1 |
| C11 | 13000463 | Screw-ST2.9×13(with washer) | 1 |
| C12 | 05030007 | Bnt85 Main Gear | 1 |
| C13 | 05030009 | Bnt85 Drive Gear | 1 |
| C14 | 05056098 | Motor Pin | 1 |

| | | | |
|-----|-----------|--------------------------|---|
| C15 | 05030005 | Bnt85 Housing | 1 |
| C16 | 05010046 | Meter Cable Clip | 1 |
| C17 | 05010108 | Meter Cable | 1 |
| C18 | 12100024 | Communication Cable | 1 |
| C19 | 30110005 | Rubber Sleeve | 1 |
| C20 | 05056013 | Communication Cable Clip | 1 |
| C21 | 05010029B | Power Cable | 1 |
| C22 | 05010035 | Power Cable Clip | 1 |

BYPASS PARTS LIST




| | | | |
|-----|-----------|------------------------------|---|
| D22 | 21709003 | Secure Clip Inlet and Outlet | 2 |
| D23 | 21319016 | Connector NPT 3/4" Straight | 2 |
| | 21319011 | Connector NPT 1" Straight | 2 |
| D24 | 26010143 | O-ring on Inlet and Outlet | 2 |
| D25 | 05056212 | 063 Bypass Body | 1 |
| D26 | 70020007M | Bypass Tool | 1 |

| No. | Part # | Description | Qty |
|-----|-----------|-------------------------|-----|
| D1 | 05056129 | O-ring-φ23×3 | 3 |
| D2 | 05010083 | Adaptor Distributor | 1 |
| D3 | 05056025 | Adaptor Coupling | 1 |
| D4 | 26010046 | O-ring-φ27×3 | 1 |
| D5 | 05010106 | Impeller Holder | 1 |
| D6 | 02170055 | Meter Assy | 1 |
| D7 | 05040129 | Meter Ball | 1 |
| D8 | 05010019B | Bush | 2 |
| D9 | 02170264 | Meter Spare Parts | 1 |
| D10 | 05056044B | SS Plate | 2 |
| D11 | 05056141B | Washer | 2 |
| D12 | 21389012 | Thumb Screw | 2 |
| D13 | 05056134 | O-ring-φ12×3 | 2 |
| D14 | 05056146 | Bypass Plug | 2 |
| D15 | 21709004 | Shaft Clip | 2 |
| D16 | 05056172N | Plug Clip | 2 |
| D17 | 05056149B | Shaft Seal | 2 |
| D18 | 05030013 | O-ring-φ30×2.65 | 1 |
| D19 | 05056214 | Bypass Shaft(Outlet) | 1 |
| D20 | 05056213 | Bypass Shaft(Inlet) | 1 |
| D21 | 61045012 | Bypass Indication Plate | 1 |

PRE-INSTALLATION INSTRUCTIONS

Contact your local distributor to have a complete water analysis and check your water hardness on your water supplier, this will keep your conditioner in proper working.



NOTE

YOU MUST FOLLOW ALL GOVERNMENT CODES AND REGULATIONS GOVERNING THE INSTALLATION OF THESE DEVICES.

INSTALLATION INSTRUCTIONS



DETERMINE THE CORRECT LOCATION OF THE WATER CONDITIONING EQUIPMENT

Select the location of your softener with care. Review the various conditions below to determine a proper location:

1. Locate as close as possible to the water supply source.
2. Locate as close as possible to a floor or laundry tub drain.
3. Locate in correct relationship to other water conditioning equipment (See Fig. 1).
4. Softener should be located in the supply line before the water heater. Temperatures above 120°F damage softeners.
5. Do not install a softener in a location where freezing temperatures occur. Freezing may cause permanent damage to this type of equipment and will void the factory warranty.
6. Allow sufficient space around the unit for easy servicing.
7. Determine if additional plumbing is required if your water source is a community water supply, a public water supply or you wish to bypass water used for a geothermal heat pump, lawn sprinkling, out-buildings or other high demand applications, refer to Fig. 1).
8. Keep the softener out of direct sunlight. Heat build up from direct sunlight may soften and distort plastic parts.

TOOLS REQUIRED FOR INSTALLATION:

- ▶ Two adjustable wrenches.
- ▶ Additional tools may be required if modifications to home plumbing are required.
- ▶ Use copper, brass, or PEX pipe and fittings.
- ▶ Some codes may also allow PVC plastic pipe. Refer to local codes.
- ▶ Always install the included bypass valve, or 3 shut-off valves. Bypass valves let you turn off water to the softener for repairs, but still have water in the house pipes.
- ▶ 5/8" OD drain line is needed for the drain.



⚠ CAUTION

THE WASTE CONNECTION OR DRAIN OUTLET SHALL BE DESIGNED AND CONSTRUCTED TO PROVIDE AN AIR-GAP TO THE SANITARY WASTE SYSTEM OF 2 PIPE DIAMETERS OR 1 INCH (25MM). (WHICHEVER IS LARGER)

⚠ CAUTION

NEVER INSERT THE DRAIN LINE DIRECTLY INTO A DRAIN, SEWER LINE, OR TRAP. ALWAYS ALLOW AN AIR GAP BETWEEN THE DRAIN LINE AND THE WASTE WATER. THIS WILL PREVENT THE POSSIBILITY OF SEWAGE BEING BACK-SIPHONED INTO THE CONDITIONER.

NOTE



PERFORM ALL PLUMBING ACCORDING TO LOCAL PLUMBING CODES.

WATER BYPASS


In case of an emergency such as softener maintenance, you can isolate your water softener from the water supply using the bypass valve located at the back of the control. In normal operation the bypass is open with the ON/OFF knobs in line with the INLET and OUTLET pipes. To isolate the softener, simply rotate the knobs to the BYPASS position.

You can use your water related fixtures and appliances as the water supply is bypassing the softener. However, the water you use will be hard. To resume treated service, open the bypass valve by rotating the knobs to SERVICE position.

Please make sure bypass knobs are completely open otherwise the unsoftened water could bypass through the valve.



BYPASS NOT ALLOWED POSITION




NOTE

Please make sure bypass knobs are completely open otherwise the unsoftened water could bypass through the valve.

PROGRAMMING GUIDE

FAMILIARIZE WITH KEY PAD CONFIGURATION




MENU: This function enters the basic set up information required at the time of installation.

SET/REGEN.: This function is to press and select one item to change and accepts the values if changed.

UP/DOWN: This function is to scroll up or down the programming items and increase or decrease the values of the settings while in the programming mode.


FAMILIARIZE WITH SETTINGS

Standby Display:




If screen displays "PRESS MENU KEY 3 SEC TO UNLOCK" " Press "MENU" for 3s to unlock

Field Options Menu:



Press "MANUAL" key to enter the field options menu.
Press the "UP" and "DOWN" key to choose the options.
Press "SET/REGEN." key to activate the option and let it flash.
Press the "UP" and "DOWN" key to change the option or value.
Press the "SET/REGEN." key to confirm it.

Factory Options Menu(Manually Enter Capacity Mode)




Displayed on CALENDAR CLOCK, METER DELAYED and METER OVERRIDE regen. mode.

Displayed on METER IMMEDIATE, METER DELAYED and METER OVERRIDE regen. mode.

Displayed on CALENDAR CLOCK and METER OVERRIDE regen. mode.

Press and hold "UP" and "DOWN" keys for 3 seconds to enter the factory option.
Press the "UP" and "DOWN" key to choose the options.
Press "SET/REGEN." key to activate the option and let it flash.
Press the "UP" and "DOWN" key to change the option or value.
Press the "SET/REGEN." key to confirm it.

Factory Options Menu(Automatically Calculate Capacity Mode)



Press and hold "UP" and "DOWN" keys for 3 seconds to enter the factory option.

Press the "UP" and "DOWN" key to choose the options.

Press "SET/REGEN." key to activate the option and let it flash.

Press the "UP" and "DOWN" key to change the option or value.

Press the "SET/REGEN." key to confirm it.

| PARAMETER | | DESCRIPTION |
|-------------------|-----------------|--|
| Current Time | | Current time setting. |
| Current Date | | Year, month and date setting. |
| Number People | | Number of people in the household and the calculated reserve capacity. When remaining reaches reserve capacity a regeneration will be scheduled. |
| Water Hardness | | This value is water hardness of the raw water supply. It is used to calculate the system capacity. |
| Vacation Mode | | When set to YES, the system will perform a Backwash and a Rinse if there is no water flow detected after 7 days. The Backwash and Rinse duration can be set in the Regeneration Cycle. |
| System Language | | System language used on the valve display, 3 different language options in total for your choice. English, Spanish, Francais. |
| Valve Operation | | The current setting of the valve mode, 3 different modes for your choice. Softener, Filter and Iron Filter. |
| Regen. Mode | Calendar Clock | The unit will initiate a regeneration at the next pre-set regeneration time based on the interval of days between regeneration days. |
| | Meter Immediate | The unit will initiate a regeneration immediately after the system capacity remaining reaches zero. |
| | Meter Delayed | When the system capacity remaining reaches zero, the system will initiate a regeneration at the next pre-set regeneration time. |
| | Meter Override | When the volume remaining goes below the system capacity, the system will regenerate at the regen time or when REGEN. DAYS preset has passed. Which ever occurs first. |
| Regeneration Time | | This setting controls the time of day when a regeneration will start. |
| Capacity Calc. | Automatic | When the necessary factory options were entered. The system will automatically calculate system capacity and refill time. |
| | Manual | Manually enter the system capacity and refill time for system proper operation. |
| Resin Volume | | This setting is the amount of ion exchange media used in the system. The value is used to calculate system capacity and refill time. |
| Salt Setting | | This setting will determine the salt dosage used per regeneration. |
| Refill Flow Rate | | This value should match the BLFC flow washer. It is used to calculate the refill time. |
| Unit Capacity | | This setting is the total hardness the system can treat after one complete regeneration. |
| Reserve Capacity | | This value is used to calculate the reserve capacity. Reserve Capacity = No. People x DAILY RESERVE. |
| Capacity | | This setting is the total water volume the system can treat after one complete regeneration. |
| Regen. Cycle | Backwash | Control the backwash duration during regeneration cycle. |
| | Brine/Rinse | Control the brine duration during regeneration cycle. |
| | Rapid Rinse | Control the rinse duration during regeneration cycle. |
| | Refill | Control the refill duration during regeneration cycle. |
| Restore Defaults | | Restore settings to the factory default. |

OPERATION DURING A POWER FAILURE

In the event of a power failure, the valve will keep track of the time and day. The programmed settings are stored in a non-volatile memory and will not be lost during a power failure. If power fails while the unit is in regeneration, the valve will finish regeneration from the point it is at once power is restored. If the valve misses a scheduled regeneration due to a power failure, it will queue a regeneration at the next regeneration time once power is restored.

START-UP INSTRUCTIONS

1. Add two liters of water into the cabinet at the time of installation. This is for the unit to achieve proper capacity in the first time of regeneration.
2. Plug the power transformer into an approved power source. Connect the power cord to the valve.
3. When power is supplied to the control, the screen will may display "INITIALIZING WAIT PLEASE" while it finds the service position.



4. Manually step the valve to the BACKWASH position. If screen is locked, the screen will display "PRESS MENU KEY 3 SEC TO UNLOCK". Follow the instructions below to step the valve to BACKWASH position. As the valve arrives at BACKWASH position, unplug the power and let valve stay at BACKWASH position.

- 4.1 Press and hold "MENU" key for 3s to unlock.

PRESS MENU KEY
3 SEC TO UNLOCK

- 4.2 Press and hold "CONFIRM" key for 3s to advance to MANUAL REGEN menu.

MANUAL REGEN.
DELEY IMMEDIAT

- 4.3 Press CONFIRM key again to let the option flash.

MANUAL REGEN.
DELEY IMMEDIAT

- 4.4 Press DOWN key to advance to IMMEDIATE option.

MANUAL REGEN.
DELEY IMMEDIAT

4.5 Press CONFIRM key to confirm and press MENU key to have an manual regeneration.

MANUAL REGEN.
DELEY IMMEDIAT

NOTE: If you select "DELAY" option, the valve will start to regenerate at the closest day's REGEN. TIME (default is 02:00)

5. Slowly open the inlet knob on the bypass valve with the bypass tool supplied and allow water to enter the unit. Allow all air to escape from the unit before turning the bypass fully open. Then allow water to run to drain for 3-4 minutes or until all media fines are washed out of the conditioner indicated by clear water in the drain hose. Open a cold soft water tap nearby and let water run a few minutes or until the system is free of foreign material resulting from the plumbing work. Close the water tap when water runs clean.


6. Press any button to advance to the BRINE position, when it arrives, press any key to skip the BRINE cycle. Press any button to advance to the RINSE position. Check the drain line flow. Allow the water to run for 3-4 minutes or until the water is clear.

7. Press any button to advance to the REFILL position. Check that the valve is filling water into the brine tank. Allow the valve to refill for the full amount of time as displayed on the screen to insure a proper brine solution for the next regeneration.

8. The valve will automatically advance to the SERVICE position. Open the outlet knob on the bypass with the bypass tool supplied. With the bypass open, open the nearest treated water faucet and allow the water to run until clear.

9. Add salt into the cabinet. Put 40 kgs of crystal water softener salt in the 1035 softener cabinet or 15kgs of crystal water softener salt in the 1017 softener cabinet. The unit will automatically fill the water to the correct level when it regenerates.

10. Program unit.



CAUTION

LIQUID BRINE WILL IRRITATE EYES, SKIN AND OPEN WOUNDS - GENTLY WASH EXPOSED AREA WITH FRESH WATER. KEEP CHILDREN AWAY FROM YOUR WATER CONDITIONER.

AUTOMATIC RAW WATER BYPASS DURING REGENERATION

The regeneration cycle can last 60 minutes after which Softened water service will be restored. During regeneration, un-Softened water is automatically bypassed for use in the household. Hot water should be used as little as possible during this time to prevent un-Softened water from filling the water heater. This is why automatic regeneration is set for sometime during the night and manual regenerations should be performed when little or no water will be used in the household.

MAINTENANCE INSTRUCTIONS

CHECK THE SALT LEVEL

Check the salt level monthly. Remove the lid from the cabinet or brine tank, make sure salt level is always above the brine level.

NOTE


YOU SHOULD NOT BE ABLE TO SEE WATER IN THE CABINET OR BRINE TANK.

ADDING SALT

Use only clean salt labeled for water conditioner use, such as crystal, pellet, nugget, button or solar. The use of rock salt is discouraged because it contains insoluble silt and sand which build up in the brine tank and can cause problems with the system's operation. Add the salt directly to the tank, filling no higher than the top of the brine well.

BRIDGING

Humidity or the wrong type of salt may create a cavity between the water and the salt. This action, known as "bridging", prevents the brine solution from being made, leading to your water supply being hard.



If you suspect salt bridging, carefully pound on the outside of the plastic cabinet or pour some warm water over the salt to break up the bridge. This should always be followed up by allowing the unit to use up any remaining salt and then thoroughly cleaning out the cabinet. Allow four hours to produce a brine solution, then manually regenerate the softener.

Resin Cleaner

An approved resin cleaner must be used on a regular basis if your water supply contains iron. The amount of resin cleaner and frequency of use is determined by the quantity of iron in your water (consult your local representative or follow the directions on the resin cleaner package).



Care of Your Water Conditioner

To retain the attractive appearance of your new water conditioner, clean occasionally with a mild soap solution. Do not use abrasive cleaners, ammonia or solvents. Never subject your conditioner to freezing.

SERVICE THE BNT850SE CONTROL VALVE

Before Servicing




1. Turn off water supply to conditioner using the bypass tool attached on the bypass.



2. Relieve water pressure in the conditioner by stepping the control into the backwash position momentarily. Return the control to the In Service position.

3. Unplug electrical cord from outlet.





4. Disconnect drain line connection.



5. Remove the cover and disconnect the wire connection.

6. Disconnect the brine line.

7. Remove the clips that connect control valve and bypass.



8. Disconnect the softener from the bypass.

9. Remove the tank with valve out the cabinet.

10. Screw the valve off from the tank.

11. Remove the top cone from the valve.



CAUTION


ELECTRICAL SHOCK HAZARD! UNPLUG THE UNIT BEFORE REMOVING THE COVER OR ACCESSING ANY INTERNAL CONTROL PARTS.




CAUTION

DISASSEMBLY WHILE UNDER PRESSURE CAN RESULT IN FLOODING. ALWAYS FOLLOW THESE STEPS PRIOR TO SERVICING THE VALVE.


REPLACE TIMER




1. Disconnect the meter cable from the meter. (If meter cable is attached).




2. Remove the two screws from the valve cover.




3. Remove the cover of the valve and disconnect the wires attached on PCB.



4. Remove the piston screw and washer from the piston rod.




5. Remove the two screws from the powerhead as shown.



6. Lift the powerhead from the valve body assembly.


7. Replace the powerhead by reverse following the steps in this section.

REPLACE PISTON AND/OR BRINE VALVE




1. Follow steps 1 to 6 of timer /Powerhead replacement.

2. Remove three screws from the plate on the valve body.



3. Remove the plate from the valve body and pull the Piston Assembly from the valve. The brine valve assembly can also be removed in this stage.


REPLACE SEAL AND/OR SPACER




4. Remove the seals and spacers assembly, grease it with silicone lubricant and put back in.

5. After servicing, reverse following steps in this section.


REPLACE METER




1. Disconnect the meter cable from the meter. (If flow meter cable is attached)




2. Disconnect the bypass from valve by removing clips.



3. Remove the coupling adapter from the bypass.




4. Remove the meter support from the bypass.




5. Remove the meter and replace it.

CLEAN INJECTOR ASSEMBLY




- 1.** Remove the two screws of the injector cap.
- 2.** Pull the injector cap out, watch for the o-ring on the cap.
- 3.** Screw the injector assembly out, clean/replace it.
- 4.** Pull the screen out, clean/replace it.
- 5.** After servicing, reverse following steps in this section.

REPLACE DRAIN LINE FLOW CONTROL





1. Pull the drain line clip and remove the drain line elbow and washer.
2. Clean/replace drain line flow control.

REPLACE BRINE LINE FLOW CONTROL





1. Screw the copper fitting out.
2. Remove the retainer out.
3. Clean/replace the BLFC button.

REPLACE MOTOR




1. Follow steps 1 to 3 of Timer /Powerhead replacement.
2. Remove the two screws from the motor. Remove motor(disconnect the wire attached on PCB if any), watch for the pin under the motor.
3. Replace the motor.

REPLACE CIRCUIT BOARD




1. Follow steps 1 to 3 of timer /Powerhead replacement.
2. Remove all the connections on PCB.
3. Remove the four screws from the PCB.
4. Replace the PCB.


REPLACE DISPLAY




1. Remove the cover from the cabinet.
2. Disconnect the wire connection.




3. Remove the four screws attached on back cover.



4. Remove the back cover.



5. Remove the four screws attached on PCB.



6. Remove the display.

TROUBLE SHOOTING GUIDE

| Problem | Possible Solutions |
|---|---|
| 1. CONDITIONER DELIVERS HARD WATER A. Bypass valve is open B. No salt in brine tank C. Injector or screen plugged D. Insufficient water flowing into brine tank E. Leak at distributor tube F. Internal valve leak G. Flow meter jammed H. Flow meter cable disconnected or not plugged into meter cap I. Improper programming | A. Close bypass valve B. Add salt to brine tank and maintain salt level above water level C. Replace injectors and screen D. Check brine refill time and clean brine line flow control if plugged E. Make sure distributor tube is not cracked. Check O ring and tube pilot F. Replace seals and spacers and/or piston G. Remove obstruction from flow meter H. Check meter cable connection to timer and meter cap I. Reprogram the control to the proper regeneration type, inlet water hardness, capacity or flow meter size. |
| 2. CONDITIONER FAILS TO REGENERATE A. Electrical service to unit has been interrupted B. Timer is not operating properly C. Defective valve drive motor D. Improper programming | A. Assure permanent electrical service (check fuse, plug, chain or switch) B. Replace timer C. Replace drive motor D. Check programming and reset as needed |
| 3. UNIT USES TOO MUCH SALT A. Improper salt setting B. Excessive water in brine tank C. Improper programming | A. Check salt usage and salt setting B. See #7 C. Check programming and reset as needed |
| 4. LOSS OF WATER PRESSURE A. Iron build-up in line to water conditioner B. Iron build-up in water conditioner C. Inlet of control plugged due to foreign material broken loose from pipes by recent work done on plumbing system. | A. Clean line to water conditioner B. Clean control and add resin cleaner to resin bed. Increase frequency of regeneration C. Remove piston and clean control |
| 5. LOSS OF RESIN THROUGH DRAIN LINE A. Air in water system B. Drain line flow control is too large | A. Assure that well system has proper air eliminator control. Check for dry well condition. B. Ensure drain line flow control is sized |
| 6. IRON IN CONDITIONED WATER A. Fouled resin bed B. Iron content exceeds recommended parameters | A. Check backwash, brine draw and brine tank fill. Increase frequency of regeneration. Increase backwash time. B. Add iron removal filter system |
| 7. EXCESSIVE WATER IN BRINE TANK A. Plugged drain line flow control B. Brine valve failure C. Improper programming | A. Clean flow control B. Replace brine valve C. Check programming and reset as needed |
| 8. SALT WATER IN SERVICE LINE A. Plugged injector system B. Timer not operating properly C. Foreign material in brine valve D. Foreign material in brine line flow control E. Low water pressure F. Improper programming | A. Clean injector and replace screen B. Replace timer C. Clean or replace brine valve D. Clean brine line flow control E. Raise water pressure F. Check programming and reset as needed |
| 9. CONDITIONER FAILS TO DRAW BRINE A. Drain line flow control is plugged B. Injector is plugged C. Injector screen is plugged D. Line pressure is too low E. Internal control leak F. Improper programming G. Timer not operating properly | A. Clean drain line flow control B. Clean or replace injectors C. Replace screen D. Increase line pressure (line pressure must be at least 20 psi at all times) E. Change seals and spacers and/or piston assembly F. Check programming and reset as needed G. Replace timer |
| 10. CONTROL CYCLES CONTINUOUSLY A. Timer not operating properly B. Faulty microswitches and/or harness C. Faulty cycle cam operation | A. Replace timer B. Replace faulty microswitch or harness C. Replace cycle cam or reinstall |
| 11. DRAIN FLOWS CONTINUOUSLY A. Foreign material in control B. Internal control leak C. Control valve jammed in backwash, brine or rinse position D. Timer motor stopped or jammed teeth E. Timer not operating properly | A. Remove piston assembly and inspect bore. Remove foreign material and check control in various regeneration positions B. Replace seals and/or piston assembly C. Replace piston and seals and spacers D. Replace timer motor and check all gears for missing teeth E. Replace timer |

